

Upgrade Manual for Patch

- 1. Preparation**
- 2. How to upgrade using USB**
- 3. Upgrade process**
- 4. How to handle abnormal cases**


April 7th ,2015

1. Preparation

- ① 150MB USB memory

2. How to upgrade using USB


- ① Unzip the downloaded file.
- ② Check if there are a patch folder and upgrade.lgu file as shown below.
- ③ Plug a USB device into your laptop and copy all files to the root directory on USB stick.




<Fig. 2-1>

3. Upgrade process(1/4)

- ① Insert USB stick with upgrade file into MediaNav.




- ② After approximately 4 ~ 5 seconds, a popup message "Reading USB device..." will appear on the screen.



3. Upgrade process(2/4)

- ③ Press “Update” button to start upgrading process.
 - It will take approximately 6 ~ 7 seconds until the upgrade process is completed.
 - Once the upgrade is complete, it will reboot the system automatically.



<Fig. 3-3>


CAUTION

DO NOT remove USB device or turn off the engine until the upgrade process is completed.

- ✓ If you accidentally remove your USB, please refer to <Fig. 4-1> on page7.
- ✓ If 『Software update』 screen does not appear, please refer to <Fig. 4-4> on page8.

3. Upgrade process(3/4)

- ④ Upgrade process will restart automatically after rebooting the system once or twice.
 - Rebooting the system will take approximately 4 ~ 5 seconds and updating will take a few minutes. Once the upgrade is complete, it will reboot the system automatically.



<Fig. 3-4>

CAUTION


DO NOT remove USB device or turn off the engine until the upgrade process is completed.

- ✓ If you accidentally remove your USB, please refer to <Fig. 4-2> on page7 and <Fig. 4-3> on page8.
- ✓ If an error message displays, please refer to <Fig. 4-4> on page8.

3. Upgrade process(4/4)

⑤ Upgrade complete

- After the reboot, the system will be ready for operating an updated version in 2 ~ 3 seconds.
- Once the upgrade is complete after a few minutes, the latest screen before upgrading the system will display.




<Fig. 3-5>


⑥ When system upgrades successfully completed, please remove USB memory.

4. How to handle abnormal cases(1/2)

- ① When upgrade is cancelled by removing USB accidentally during 1st upgrading.
- Re-insert the USB stick into HU and start upgrading again.



- ② When upgrade is cancelled by removing USB accidentally during 2nd upgrading.
- In this case, you need to insert the USB stick into HU within 90 seconds to restart upgrading.




CAUTION

DO NOT remove USB device or turn off the engine until the upgrade process is completed.

4. How to handle abnormal cases(2/2)

- ③ When not inserting USB within 90 seconds after you accidentally removed your USB device.
- A screen with Cancel button will display.
 - If you press “Cancel” button, upgrading will be cancelled temporarily. If you would like to upgrade the system, please insert USB.



- ④ When you cannot find a upgrade file in the root directory of your USB device.
- Please check the root directory of your USB device as shown below.

